

「魔獣の王国」、「DEVIL WORLD」は、弊社(コナミ)が独自に開発したオリジナル製品であり、著作権、工業所有権、その他の諸権利はコナミ株式会社が所有しております。

FDEVIL WORLD, is an original game developed by KONAMI Industry Co., Ltd., KONAMI Industry Co., Ltd., reserves all the copyrights, trademarks and other industrial property rights with respect to this game.

CONSTRUCTION ON THE PROPERTY OF THE PROPERTY O

# DEVIL WORLD

# ティップスイッチNo.1セット

#### 1. コインスイッチ№1セット

| SW  | 1   | 2   | 3   | 4      | コイン | プレイ |
|-----|-----|-----|-----|--------|-----|-----|
| 0   | OFF | OFF | OFF | OFF    | 1   | 1   |
|     | ON  | OFF |     |        | 1   | 2   |
|     | OFF | ON  |     | Blue B | 1   | 3   |
|     | ON  | ÓN  |     |        | 1   | 4   |
|     | OFF | OFF | ON  | OFF    | 1   | 5   |
|     | ON  | OFF |     |        | 1   | 6   |
|     | OFF | ON  |     |        | 1   | 7   |
| 950 | ON  | ON  |     |        | 2   | 1   |
|     | OFF | OFF | OFF | OFF ON | 2   | 3   |
|     | ON  | OFF |     |        | 2   | 5   |
|     | OFF | ON  |     |        | 3   | 1   |
|     | ON  | ON  |     |        | 3   | 2   |
|     | OFF | OFF | ON  | ON ON  | 3   | 4   |
|     | ON  | OFF |     |        | 4   | 1   |
|     | OFF | ON  | 27  |        | 4   | 3   |
|     | ON  | ON  |     |        | フリー | プレイ |

# (注意) フリーブレイとはコインを投入せずプレイできる状態をいう。

#### 2. コインスイッチ№2セット

| SW    | 5   | 6   | 7   | 8     | コイン | フレイ |
|-------|-----|-----|-----|-------|-----|-----|
| 0     | OFF | OFF | OFF | OFF   | 1   | 1   |
|       | ON  | OFF |     |       | 1   | 2   |
|       | 0FF | ON  |     |       | 1   | 3   |
|       | ON  | ON  |     |       | 1   | 4   |
|       | OFF | OFF | ON  | OFF   | 1   | 5   |
|       | ON  | OFF |     |       | 1   | 6   |
|       | OFF | ON  |     |       | 1   | 7   |
|       | ON  | ON  |     |       | 2   | 1   |
|       | OFF | OFF | OFF | ON    | 2   | 3   |
|       | ON  | OFF |     |       | 2   | 5   |
|       | OFF | ON  |     |       | 3   | 1   |
|       | ON  | ON  |     |       | 3   | 2   |
|       | OFF | OFF | ON  | ON ON | 3   | 4   |
| 2     | ON  | OFF |     |       | 4   | 1   |
| - Jau | OFF | ON  |     |       | 4   | 3   |
| 7-    | ON  | ON  |     | 1000  | 無   | 90  |

# ディップスイッチ No2セット

## 1. プレイヤー数

|   | 1   | 2   | プレイヤー数 |   |
|---|-----|-----|--------|---|
|   | OFF | 0FF | 2      |   |
| 0 | ON  | OFF | 3      |   |
|   | OFF | ON  | 5      | - |
|   | ON  | ON  | 7      |   |

# 2. ゲームの難度

| SW | 6   | 7   | 難度    | 11100 |
|----|-----|-----|-------|-------|
|    | OFF | OFF | 易しい   |       |
| 0  | ON  | OFF | 普通    |       |
|    | OFF | ON  | 難しい   | 7100  |
|    | ON  | ON  | 大変難しい |       |

# 3. アモ中の音

| SW | 8   | 音 |
|----|-----|---|
|    | OFF | 無 |
| 0  | ON  | 有 |

SW3~SW5は未使用

## DIP SWITCH No. I SETTINGS

## 1 . COIN SWITCH No.1 SETTINGS

| SW    | 1   | 2   | 3    | 4   | COIN | PLAY |
|-------|-----|-----|------|-----|------|------|
| 0     | OFF | OFF | OFF  | OFF | 1    | 1    |
|       | ON  | OFF |      |     | 1    | 2    |
|       | OFF | ON  |      |     | 1    | 3    |
|       | ON  | ON  |      |     | 1    | 4    |
|       | OFF | OFF | ON   | OFF | 1    | 5    |
|       | ON  | OFF |      |     | 1    | 6    |
|       | OFF | ON  |      |     | 1    | 7    |
|       | ON  | ON  |      |     | 2    | 1    |
|       | OFF | OFF | OFF  | ON  | 2    | 3    |
|       | ON  | OFF |      |     | 2    | 5    |
|       | OFF | ON  | IL.  |     | 3    | 1    |
|       | ON  | ON  |      |     | 3    | 2    |
|       | OFF | OFF | ON   | ON  | 3    | 4    |
|       | ON  | OFF | 7c   |     | 4    | 1    |
|       | OFF | ON  |      |     | 4    | 3    |
| ASSES | ON  | ON  | 5- 1 | 1   | FREE | PLAY |

(Nôte) Free Play: You can play games without coin.

#### 2. COIN SWITCH No2 SETTINGS

| SW | 5   | 6   | 7   | 8  | COIN | PLAY |
|----|-----|-----|-----|--|------|------|
| 0  | OFF | OFF | OFF | OFF  | 1    | 1    |
|    | ON  | OFF |     |  | 1    | 2    |
|    | OFF | ON  |     |  | 1    | 3    |
|    | ON  | ON  |     | SECURIAL DESCRIPTION OF THE PERSON OF THE PE | 1    | 4    |
|    | OFF | OFF | ON  | OFF  | 1    | 5    |
|    | ON  | OFF |     |  | 1    | 6    |
|    | OFF | ON  |     |  | 1    | 7    |
|    | ON  | ON  |     |  | 2    | 1    |
|    | OFF | OFF | OFF | F ON   | 2    | 3    |
|    | ON  | OFF |     |  | 2    | 5    |
|    | OFF | ON  |     |  | 3    | 1    |
|    | ON  | ON  |     |  | 3    | 2    |
|    | OFF | OFF | ON  | ON .   | 3    | 4    |
|    | ON  | OFF |     | 60/3 F   | 4    | 1    |
|    | OFF | ON  |     |  | 4    | 3    |
|    | ON  | ON  |     | - 3  | VO   | ID   |

# DIPSW No 2 SETTINGS

## 1. The Number of Player's Life

|   | 1   | 2 ' | Number |
|---|-----|-----|--------|
|   | OFF | 0FF | 2      |
| 0 | ON  | OFF | 3      |
|   | OFF | ON  | 5      |
|   | ON  | ON  | 7      |

# 2. Difficulty of The Game

| SW  | 6   | 7   | Difficulty     |
|-----|-----|-----|----------------|
|     | OFF | OFF | Easy           |
| 0   | ON  | OFF | Normal         |
| 4   | OFF | ON  | Difficult      |
| 0.7 | ON  | ON  | Very Difficult |

## 3. Sound in Attractive Mode

| SW  | 8   | Sound           |  |
|-----|-----|-----------------|--|
| OFF | OFF | No. of the last |  |
| 0   | ON  | ON              |  |

SW3 thru SW5 are not used.

## ディップスイッチ No3セット

#### 1. ピアオスクリーン反転切り換え

| SW | 1   | モニター |
|----|-----|------|
| 0  | OFF | 正常   |
|    | ON  | 反転   |

#### 2. モード切り換え

| SW  | 3   | モード     |
|-----|-----|---------|
| 0   | OFF | ゲームモード  |
| Da. | ON  | ・テストモード |

SW2、SW4は未使用 〇臼は標準設定

## セルフ・テスト

正常な場合: "OK"と表示後、ゲームが始まる。

異常な場合: "BAD"と表示され、異常がある場合はチェ

ツクを繰り返します。

## マニュアルテスト

#### a 起動方法

アイツブスイツチNo3のSW3をONにして電源を 入れることにより、マニュアルテストが行なえます。

- b テスト項目
  - 1 カラーチェック

………モニターの色調のチェック。

- 2 コントロールチェック
  - ……押されたスイッチの数字が"1"に変わります。
- 3 コインカウンターチェック
- …コインカウンター1、2とも10回ずつカウントします。
- 4 ティップスイッチ設定
  - …ティップスイッチを変化させ設定を確認して下さい。
- 5 サウンドチェック
  - ......4秒毎に次のサウンドを鳴らします。
- 6 画面反転チェック
- ………ノーマル状態と反転状態を繰り返します。
- ☆ MAPボタンを押すことによってテスト項目が移行します。
- ☆ サウンドチェック時は、1P スタート (1 Pパワーアップ) ボタンを押すことによって、サウンドコードが移行します。

# DIPSW No.3 SETTINGS

#### 1. Video Screen Flip

| SW | 1   | Flip        |
|----|-----|-------------|
| 0  | OFF | Normal      |
|    | ON  | Upside Down |

#### 2. Change of Mode

| SW | 3   | Mode       |
|----|-----|------------|
| 0  | 0FF | Game Mode  |
|    | ON  | Check Mode |

SW2 and SW4 are not used.

O shows recommended settings

#### Self Test

Normal: "OK" will be displayed. Then game program will be started.

Abnormal: "BAD" will be displayed and self test will repeat itself.

## Manual Test

- a. How to start.
- Turn on the Power while the SW3 of the DIP SW No,3 is on.
- b. Test Items.
- 1 Color Conditioning
- 2 Control Check
- 3 Coin Counter Check
- 4 DIP SW SET
- 5 Sound Check
- 6 Video Screen Flip
- ☆ To change items, push MAP button.
- ☆ Push 1P START (POWER UP) button to change sound.

## 技術的な説明

(1)P.Cボードの電源仕様 GND-Vcc 5V 7A以上

GND-(+12V) 束線図参照

(2)モニターへの接続は、国内で販売されている、一般的 なカラーモニターに接続可能です。

(3)音量の調節は、P.Cボード上のボリュームで行い、右 へ回すと大きくなります。

(4)P.Cポードは精密装置のため、運送時などは、取扱い 方に注意して下さい。

## コントロールパネルに関して

8方向レバー3ショットボタンのペアプレイバネルを使用 し、コンパネ中央にMAPボタンを取付けて下さい。1P、 2Pのスタートボタンがあるコンパネなら、1Pスタート ボタンをMAPボタンとして使用できます(2Pスタート ボタンは使用しません。) ゲームスタートボタンはパワー アップボタンと併用します。

#### 遊び方

#### 1.ストーリー

古代遺跡より自らの手で発堀した魔王の枢を世に報道 しようとした考古学者コンドル教授は、記者会見の場 で女性レポーターラブライナと共に枢から蘇った魔王 に魔界へと連れ去られてしまう。果たして彼らは魔王 を倒し、自分達の世界へ無事戻ることが出来るのだろ うか。

## II. 遊び方

- ○左側(LABRYNA)、右側(CONDOR)で同時に プレイが出来ますし片側だけでも遊べます。
- いつでもどこでも、ゲームに参加出来ます。(途中参
- ○コンティニューは、1ゲーム中3回まで出来ます。
- ○最終ステージでは、コンティニュー、途中参加が出 来なくなります。
- ○コイン投入後、スタートボタン (パワーアップボタ ンと同じ)を押すとゲームスタート。
- 8方向レバーでプレイヤーを操作します。
- ○ショットボタンで武器を使用し、敵を倒します。
- ○ジャンプボタンで障害物等を飛び越えます。
- ○MAPボタンにより、KEY、EXITの位置を小画 面にて表示します。(MAPボタンは1P,2P共用)
- ○KEYを持ってEXITに入ると次のステージへ移れ ます。
- \*一部のステージでは、あるEXITに入っても、同 じステージの別のEXITに出てしまう場合もある。
- ○エネルギーが無くなると、プレイヤーが1人減りま

## Technical Information

- (1) Required Power Capacity GND-Vcc 5V 7A or more GND-(+12V) See the WIRING DIAGRAM
- (2) Output R(red) analog, positive G(green) analog, positive B(blue) analog, positive

Sync. H-V complexed, negative (3) Adjusting Volume of sound.


Turn the volume right and it becomes louder.

(4) Handle with care.

# Control Panel Information

Use a control panel as shown below. An additional button should be placed as "MAP" button in the center of the panel. Another way is to use the original 1P start button (2P start button is not used.) Power up buttons are used as start buttons for this game.





# Play Instruction


## I. Story

An archaeologist Dr.Condor found the coffin of the Devil from an ancient ruins. At the press conference to announce his achievement, the Devil suddenly revived from the coffin and took Dr.Condor and Labryna, a reporter, into the Devil World. Can they destroy the Devil and come back to this world?

#### II. How to play

- ·Two players can play at the same time. Second player can enter at anytime.
- You can continue the game up to three times by inserting additional coins. Continuation and buy-in are not available at the final stage
- Deposit coin(s) and press start (Power up) button.
- ·Use Shoot button to fire weapons and Jump button to jump over the obstacles.
- ·Pressing Map button will show you the positions of keys and exits on the map.
- ·Come to an exit with a key to move to the next stage. \*Certain exits do not lead to a different stage but to another door of the same stage.
- ·You will lose one life when your energy runs out. Take food to restore your energy.

# DEVIL WORLD



1